

## Week 2 Prelab

Calculate the ratio RMS/V<sub>pp</sub> for the following signals. Show all your work!


Name: Kyle Colpe

UID: 405016683

1. Square Wave: RMS / V<sub>pp</sub> = ?

$$V_{pp} = a - (-a) = 2a$$

$$\int^2(t) = a^2$$



$$RMS = \sqrt{\frac{1}{T} \int_0^T a^2 dt}$$

$$= \sqrt{\frac{a^2 T}{T}}$$


$$= \sqrt{a^2} = a$$

$$\frac{RMS}{V_{pp}} = \frac{a}{2a} = \boxed{\frac{1}{2}}$$

2. Triangular Wave: RMS / V<sub>pp</sub> = ?

$$V_{pp} = 2a$$

$$f(t) = \frac{a}{t_1} \cdot t$$



$$RMS = \sqrt{\frac{1}{T} \int_0^{t_1} \frac{a^2 t^2}{t_1^2} dt}$$

$$= \sqrt{\frac{a^2}{T t_1^2} \cdot \frac{1}{3} t^3 \Big|_0^{t_1}}$$

$$= \sqrt{\frac{a^2 t_1}{3T}} \xrightarrow{T=t_1} \sqrt{\frac{a^2}{3}}$$

$$\frac{RMS}{V_{pp}} = \frac{a}{\sqrt{3}} \cdot \frac{1}{2a} = \boxed{\frac{1}{2\sqrt{3}}}$$

3. If you see a difference by a factor of 10 between the oscilloscope reading and the function generator setting, where is the first place that you should look? Watch the Probe Setting video (<https://youtu.be/dtSuTHlviSo>) for the answer.

The channels will indicate the attenuation of the probe. Hence, we look at the channels and set them to the proper attenuation.



4. If you see a difference by a factor of 2 between the oscilloscope reading and the function generator setting, where is the first place that you should look? Watch the Function Generator Output Impedance video (<https://youtu.be/-8Dv1oOjD9w>) for the answer.

I should look towards the ability to properly match the load  
expectation between the function generator and the oscilloscope.

In particular, the  
output impedance of  
the function generator  
should match the  
input impedance of the  
oscilloscope.

5. Why would you ever want to use AC coupling on an oscilloscope? Watch the AC Coupling video (See CCLE) for the answer.

AC Coupling blocks the DC level of the input and increases the sensitivity  
of the signal. AC Coupling allows us to see the real structure of the waveform.

**Week 2 Prelab End**